

| | | |
|--|--|--|
| | KATHMANDU UPATYAKA KHANEPANI LIMITED | No. Effective Date: Revision No: 00 |
| | STANDARD OPERATING PROCEDURE | |
| | ELECTRIC CONDUCTIVITY HAANNA HI2003 | |

1. Scope

To provide a standard operating procedure for determining the electric conductivity of water samples following Standard Methods.

2. Principle

The ability of water to conduct an electric current is known as electric conductivity (EC) and depends on the concentration of ions in solution.

3. Sampling and Preservation

- Collect samples in clean glass bottles.
- Analyze the samples immediately. The samples cannot be preserved for later analysis.

4. Equipment / Apparatus

- EC meter HANNA HI2003
- Soft tissue paper
- 50mL beaker or 100mL beaker

5. Reagents

- Distilled water
- Calibration standard 1,413 $\mu\text{S}/\text{cm}$.


6. Procedure

Calibration

- Take the calibration reagent into a beaker.
- Rince the probe with distilled water then soak in the calibration solution.
- Press CAL/MODIFY key.
- Wait until the EC meter stabilizes and the "WAIT" indicator appears.
- When the reading is stabilized and close to 1,413 $\mu\text{S}/\text{cm}$, "CFM" tag will blink.
- Press GLP/CFM key.

Note: Calibration should be done daily before EC measurement.

Measurement



7. Data quality management and data reporting.

- Calculate RPD value and check the data precision.

$$\text{RPD} = (\text{Max. value} - \text{Min. value}) / \text{Average} \times 100 (\%)$$

- If RPD value exceeds 10%, measure one more time (the 3rd measurement).
- Select two (2) data that are close and recalculate RPD
- If RPD value exceeds 10%, measure one more time (the 4th measurement).
Note: If RPD value remains large, suspect contamination of sample cell and clean sample cell.

- Calculate average value using the data set (two (2) datas) that satisfies RPD value < 10%.
- Calculated average value using data set which satisfies RPD < 10% is reported as the measurement value.

8. Daily maintenance

- Cleaning prove after use.

| | | |
|--------------|--|-----------------|
| Written by: | | Signature/Date: |
| Reviewed by: | | Signature/Date: |
| Approved by: | | Signature/Date: |